www.radio-workshop.co.uk



Fig. 3.

Circuit voltages are shown within rectangles and were measured with a 20,000 Ω/V meter under no-signal conditions. Where two voltages are given, M indicates that the receiver was switched to the M range and V to the v.h.f. range.

Where the resistance of a coil is less than one ohm the value is omitted. The valve pin numbers are shown within small circles.