

C	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100	
L	5	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
R	5	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
MISC	VI		V2		S1a		S1c		S1d		S1f		S1g		S1h		S1i		S1j		V4		V8		V5a		V5b		P.U.		S1k		S1l		V6		S2		T1		V7		V9		T2		S3a		S3b		MISC																																																		

A242




Fig. 5. The circuit diagram.

The Waveband switch (S1a-S1j) is shown in the V.H.F. position and the Tone switch (S2) is shown in the minimum h.f. response position.

Circuit voltages are shown within rectangles and were measured under no-signal conditions using a 20kΩ/V meter, with the receiver switched first to the M band and then to the V.H.F. band. Where the readings differed appreciably, both are quoted with the M band reading at the top.

All resistors are rated at 0.6W excepting where otherwise indicated.

The d.c. resistance is quoted for all coils excepting where the value is less than one ohm.

Component terminals and connecting leads are identified by test point (t.p.) numbers which correspond with those appearing on the chassis diagrams. The valve pin numbers are shown in small circles.

SUBJECT TO ALTERATION WITHOUT NOTICE
ISSUE G.